

Storm Cover Fitting



ITEMS REQUIRED:

Screw Gun/Drill

Step Ladder

10-16 x 16 Metal Tek Hex Head Screws

(10 Per Side wall Storm Cover, 8 for front)

Once Storm Cover Set is removed from the bag:

1



- Slide 1 x Sail Track off Storm Cover

2

Side Wall



- Place on wall
- For side walls, push up flush to roof tab bolts

3

Front/Rear Wall



- For front and rear walls, the Sail Track goes flush with the top 50x50 box section

4



- Attach Sail Track with metal teks - evenly spaced. Track and Wall are NOT pre-drilled, Tek screws are self-drilling
- Slide Storm Cover onto Sail Track
- With slight tension on the Storm cover, attach bottom Sail Track with metal teks

Care and Maintenance

- We suggest the Storm Covers are rolled up, not folded and kept in the bag they came in.
- Keep the Covers dry and out of the weather to insure they last
- If the Covers have been off for a period of time, before attaching them, make sure the Tracks are clean
- When in use - periodically clean the Covers with a soft cloth and water