

Solution Stables

Assembly



- 8 x Drop Pins
- 3 x Roof Joining Bolts
- 4 x Roof Tabs
- 8 x Roof Tab Bolts
- 1 x Rug Rack
- 2 x Rug Rack Bolts

How to identify your Roof Panels

Identify the Roof Panels by the location of the 4 holes, this is the outside of the Roof Panels.
The holes to go to the front of the stable are set back further then the holes at the rear.



Assemble your Roof

1. The Roof Panels can be assembled either from the side of the stable, front of the stable or rear of the stable
2. Leaning the Roof Panels on the stable and using the hand over hand method, slide the roof panel on top of the stable.
3. Using a crate or step to stand on, one person balances the roof panel from outside of the stable and another person, using a broom handle or similar from inside of the stable, slide the roof panel towards the other side.
4. Move the crate or step as you need to, to get the roof panel across the whole stable.
5. Ensure the roof sheets overlap in the middle and join the Roof Panels together with 3 Roof Joining Bolts.
6. Align the holes in the roof panels with the holes in the wall panels.
7. The Roof is adjustable to overhang both at the front and rear or just overhang at the front and sitting flush at the rear. Align the holes so that you get the appropriate roof position you require.
8. Using the Roof Tabs and Roof Tab Bolts secure the roof panels to the wall panels.

NOTE: When assembling multiple stables it is important to ensure the stables are square. We recommend putting up one stable at a time complete with Roof and then joining the next stable to ensure the complex stays square.

